



75	PR-302019-00-00	摄像头支架	1PCS	摄像头支架
74	PR-302018-00-00	方向角按钮	1PCS	方向角按钮
73	PR-302017-00-00	右壳侧围	1PCS	右壳侧围
72	PP-301002-00-00	底座	1PCS	底座
71	AS-000000-03-00	TV 面板转大轴侧(带杆)	1SET	TV 面板转大轴侧(带杆)
70	TU-000204-01-00	TV 高频头	1PCS	TV 高频头
69	MP-253012-00-00	安装条	1PCS	安装条
68	MP-253009-00-00	右明起	1PCS	右明起
67	FA-253008-00-00	左明起	1PCS	左明起
66	FA-303010-00-00	风扇	1PCS	风扇
65	SR-005070-13-00	六角螺栓 (后柱)	1PCS	后柱
64	SR-003010-00-00	螺栓M2, 0x10 PA	4PCS	散轴片
63	SR-002616-00-00	螺栓M2, 0x10 PA	2PCS	风扇罩
62	SR-002608-00-00	螺栓M2, 0x8 PA	1PCS	散轴片
61	SR-002606-06-00	螺栓M2, 0x6 PA	1PCS	PC壳
60	SR-002604-01-00	螺栓M2, 0x4 PA	13PCS	PC壳
59	SR-002060-15-00	螺栓六角带帽M2, 0	1PCS	面板推杆
58	SR-002006-06-01	螺栓M2, 0x6 PA	6PCS	左右旋转支架V4, E1板V2
57	SR-002004-06-00	螺母M2x4 PPS	2PCS	SOCKET PERAL 轴压轮轴V1
56	SP-258004-00-00	压簧弹簧	1PCS	开关压块
55	SP-258003-00-00	扣簧(右壳)	1PCS	面板推杆
54	SP-258002-00-00	六角螺母	1PCS	面板推杆
53	HN-040005-00-00	六角螺母B5	1PCS	后柱
52	HN-002616-00-00	六角螺母M2, 6	2PCS	风扇罩
51	TU-002100-00-00	收音器天线	1PCS	
50		收音器	1SET	
49	Z00025-03	主板SD功能部分	1SET	
48	60107-08	连接板部件	1SET	
47	60107-05	相芯同轴板部件	1SET	
46	60107-03	主板部件	1SET	
45	FB-252001-00-00	主板绝缘铜纸	1PCS	
44	MP-258009-00-00	左旋转支架组件	1PCS	
43	MP-258008-00-00	右旋转支架组件	1PCS	
42	MP-252007-00-00	半护套	1PCS	
41	MP-252006-00-00	机芯后架	1PCS	
40	MP-252005-00-00	机芯侧架	1PCS	
39	MP-252004-00-00	散轴片	1PCS	
38	MP-252003-00-00	后架	1PCS	
37	MP-252002-00-00	面盖	1PCS	
36	MP-252001-00-00	面壳	1PCS	
35	MD-002025-00-00	轴尾轮 (齿轮)	1PCS	
34	SG-251002-00-00	硬口板前组件	1PCS	
33	SP-258022-0W-00	OD 导光块	1PCS	
32	PP-258018-30-01	E1 钮	1PCS	
31	PP-258010-00-00	开关压块	1PCS	
30	PP-258008-00-00	面板板	1PCS	
29	PP-258007-00-00	中间轴轮	1PCS	
28	PP-258006-00-00	面板推杆	1PCS	
27	PP-258003-00-00	面板板	1SET	
26		底座零件	1SET	
25	ER-000015-00-00	L型角杆	3PCS	底面板, 中间齿轮X1
24	PP-258010-00-00	左滑块	1PCS	
23	PP-258011-00-00	右滑块	1PCS	
22	SR-002006-06-00	螺栓 M2, 0x6mm	2PCS	
21	PR-302014-00-00	螺丝弹簧	1PCS	
20	SR-001508-05-01	螺栓 M2, 0x5, 8mm	6PCS	底面板
19	SP-258001-00-00	压簧弹簧	2PCS	
18	SP-251001-00-00	滑动杆柱	1PCS	
17	BR-258001-00-00	USB 盖	1PCS	
16	PR-302029-00-00	转接板垫块	1PCS	
15	PV-301001-00-00	转接板	1PCS	
14	PP-301020-00-00	转接板垫块	1PCS	
13	PR-302015-00-00	OPEN按钮	2PCS	
12	PR-302014-00-00	指示灯	1PCS	
11	PR-302013-00-00	即方向角按钮	1PCS	
10	PR-302012-00-00	即方向角按钮	1PCS	
9	PR-302011-00-00	AMS按钮	1PCS	
8	PR-302010-00-00	AMS按钮	1PCS	
7	PR-302009-00-00	POWER按钮	1PCS	
6	PR-302008-00-00	POWER按钮	1PCS	
5	PR-302007-00-00	右数字按钮	1PCS	
4	PR-302006-00-00	左数字按钮	1PCS	
3	PR-302005-00-00	侧上	1PCS	
2	PP-301004-00-00	装饰柜	1PCS	
1		前面板	1PCS	
	PR-300201-00-00	零件编号	用量	备注